

Mounting A Projector!

1. Mount the projector mount ceiling bracket to the ceiling. It is best to center the ceiling bracket to your screen. Use the necessary fasteners to attach the ceiling bracket to the ceiling.
2. If there is a ceiling bracket cover, now would be the time slide it over the ceiling bracket.
3. Attach the mount arms or feet to the projector.
4. Attach the support disc or base to the feet or arms, and tighten everything. It is best to align the supporting disc over the lens of the projector and close to the front of the projector. Depending how you attach the feet to the supporting disc, you can align the mount main different ways.
5. Attach the projector mount support disc to the ceiling bracket with the included accessories.
6. Align and tighten into place.